

# INSTALLATION INSTRUCTIONS

**Product**

7160-0916, 7170-0570

**Revision**


A

**Form**

INST-769

SHORTENED FORD NGPI UTILITY CONSOLE

Printing Spec: PS-001



These instructions are for the installation of the Gamber-Johnson Shortened Ford NGPI Utility console box. This console box is designed to fit in 2012 or later Ford NGPI Utility models not equipped with a center console. If the vehicle is not equipped with a factory front console top plate, extra hardware is included. Hardware bag 7120-0630 provides the required hardware to replace this OEM hardware.

1. Remove the lower dash trim panels on either side of the dash. See FIG 1.
2. Remove the stock tunnel plate by removing the 6 bolts.
3. Remove the USB/Audio trim panel and disconnect the cables. See FIG 1.

LOWER DASH TRIM PANEL



USB/AUDIO TRIM PANEL

FIG 1 - Lower Dash Trim

**Product Mounting Disclaimer**

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© copyright 2016 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868



11. **OPTIONAL.** If the vehicle is equipped with the factory rear wire chase a cover can be installed to tie the console box to the factory wire chase. Place the wire chase onto the rear mounting platform of the console box. The cover should angle upward to cover and hook over top of the factory wire chase. Using the rear console box mounting bolts and the OEM hardware, attach the cover to the console box and rear wire chase. See FIG 4.

NOTE: Some downward pressure on the cover may be required to align the holes in both the console box and factory wire chase.



**FIG 4** - Rear Wire Chase Cover

12. **OPTIONAL.** Accessories such as arm rests can be mounted on the rear mounting platform using the key hole slots and carriage bolts provided with these accessories. To ease installation, first place the bolts and washers through the accessory with the carriage bolt heads facing down. Just barely start the nuts on the carriage bolts so they can hang downward. With the carriage bolts hanging down, place the heads into the large opening on the key hole slots. Repeat for all four bolts on the base of the accessory, sliding it forward as you go. Pull up on the carriage bolts so the square neck of the bolt is in the slot and tighten.