

INSTALLATION INSTRUCTIONS

Product 7160-1103

Revision
Rev.A

Form

LINDE E30 LATCH MOUNTING BRACKET

Printing Spec:PS-001

The 7160-1103 Linde E30 latch mounting bracket is designed to mount to the existing door latch bracket on the Linde E30 forklift (See Figure 1 below).

Attaching the latch mounting bracket:

- 1. Mark the current location of the latch bracket on the overhead guard leg with a pencil. Then removing the hex bolts that hold the latch bracket in place.
- 2. Reattach the latch bracket and the Gamber-Johnson mounting bracket (GJ bracket on the outside) with the exiting hardware removed from step 1. Note to align the latch bracket with the pencil marks from step 1 so the door closes correctly.
- 2. 3/8" hardware has been provided in hardware bag 7120-0810 for attaching a 7160-0371 clam shell.





M8 Mounting

hardware

–Door latch bracket Gamber-Johnson mounting bracket

Figure 2.



Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.