



INSTALLATION INSTRUCTIONS

Product

7160-2056

Ford F150 headliner camera mount

Revision

Rev A

Form

INST-1226

Printing Spec: PS-001

Attach the camera mount to the headliner bracket:

1. Attach the camera mount and camera (various options available) to the headliner bracket before installing the bracket into the vehicle. See the instruction sheet for the specific camera mount being installed. *It is easier to attach the camera mounts on a bench vs attaching them from the hanging bracket. This also prevents any hardware from falling down the dash vents if the hardware is dropped.*

Attach the headliner mount (with camera attached) to the headliner:

2. Remove the plastic passenger side sun visor bracket with a 7mm socket.
3. Place the sunvisor bracket through the cutout in the headliner bracket and reattach the sun visor bracket sandwiching the mount between the bracket and the headliner.



Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brake lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© Copyright 2024 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868



Adjusting the camera mount:

4. If the camera bracket is hitting the windshield, the bracket can be adjusted by loosening the (2) #10 lock nuts that hold the camera bracket to the roof bracket. The side to side angle of the camera can also be adjusted at this same location. Adjust as needed, then re-tighten the lock nuts in place.
5. Adjust the pressure bracket against the windshield, by loosening the #10 machine screw that holds the bracket in place, adjust the bracket outward until it is pressing on the windshield and re-tighten the screw to hold it in place. This will help eliminate vibration and bounce in the camera.
Note, the pressure bracket can be moved to the opposite side of the camera bracket if that location better suits your specific vehicle.
7. Last, adjust the up and down camera angle to the desired position and tighten the mounting hardware that holds the camera in place.
8. Once powered, check the camera view position and make adjustments that best fit your specific camera angle requirements.

Images of various cameras installed

Lytx ER-SF300
camera



#10 nylock
nuts
Pressure
bracket

Samsara CM32
camera



Streamax AD Plus
camera

