



Very Well Connected™

# INSTALLATION INSTRUCTIONS

## Product

**7160-0854**

## Revision

Rev.A

## Form

INST-736

**SCANNER/MOBILE COMPUTER  
HOLDER ASSEMBLY**

**Printing Spec:PS-001**

The following instruction sheet is for mounting the scanner holder to pillars of various fork trucks.

The assembly attaches to the overhead guard leg on the fork truck. Fits rectangular pillars from 1.5" to 2.5" wide.

The mount is held in place with a back plate and 3/8" dia. carriage bolts, flat washers, lock washers and hex nuts supplied in hardware bag 7120-0608.

Use the 3.5" long bolts for pillars up to 2.75" deep.

Use the 6" long bolts for pillars up to 5.00" deep.

Position the 3/8 bolts as close to the pillar as possible to prevent bowing the components

Note the orientation of bends on backer plate



Figure 1.- Example of Assembly in Secure position

### Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© copyright 2016 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868