

Very Well Connected™

INSTALLATION INSTRUCTIONS

Product 7160-0578 **CF54 CRADLE** Revision Rev. A

Form **INST-683**

Printing Spec: PS-001

This instruction sheet is for the CF54 cradle only. For instructions on features, set-up, and operation of the CF54 computer, please refer to the manual provided by Panasonic with the computer.

This cradle is designed to be used with a variety of Gamber-Johnson mounting systems. Installation instructions for other Gamber-Johnson products are provided with each individual product.

This instruction sheet is for the following products:

Item No. 7160-0578-00 No RF Item No. 7160-0578-00-E Dual RF



Product Mounting Disclaimer

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program. © Copyright 2015 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868

CF-54 CRADLE FEATURE IDENTIFICATON





-Motion Attachment attached with (4) .25-20 n and washers

SCREEN SUPPORT ACCESSORY

Two Screen Supports (7110-1023), one installed on each side of the cradle, are recommended for installations in environments with high vibration.



INSERTING THE COMPUTER INTO THE CRADLE

1. Push the Latch Button to open the latch if the cradle is in the closed position.

2. Insert the front of the CF-54 computer under the front hooks on the cradle. Look at the handle to make sure the front of the computer is centered on the front hooks.

3. Lower the back of the computer down onto the cradle.

4. <u>Lightly press down on the back of</u> the computer to ensure it is fully seated while closing the latch.

5. The rear hooks will engage the back of the computer to hold it in place.



TO REMOVE THE COMPUTER

1. Press the Latch Button. The front latch is spring loaded and will automatically open. <u>Lightly press down on the back of the</u> <u>computer</u> and the rear hooks will retract from the computer.

2. Lift the back of the computer off the cradle.

3. Pull the front of the computer out from under the front hooks.

