



# INSTALLATION INSTRUCTIONS

<b><u>Product</u></b> 7160-1275 PANASONIC FZ-T1 TABLET CRADLE	<b><u>Revision</u></b> REV. B	<b><u>Form</u></b> INST-921  <b>Printing Spec:</b> PS-001
---	----------------------------------	--

This instruction sheet is for the Panasonic FZ-T1 Tablet cradle only. For instructions on features, set-up, and operation of the computer, please refer to the manual provided by Panasonic with the computer.

This docking station is designed to be used with a variety of Gamber-Johnson mounting systems. Installation instructions for other Gamber-Johnson products are provided with each individual product.

This instruction sheet is for the following products:

- Item No. 7160-1275-20(-P)(-E)** CRADLE, W/LOCK(External Power Supply sold separately)
- Item No. 7160-1275-10(-P)(-E)** CRADLE (External Power Supply sold separately)





**Product Mounting Disclaimer**  
Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© Copyright 2019 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868

# FEATURE IDENTIFICATION




# DOCKING AND UNDOCKING THE COMPUTER

## OPERATION - DOCKING

1. Insert the bottom of the tablet into the bottom cavity of the dock. The walls on the dock will guide the tablet into place.
2. Rotate the top of the tablet into the dock, overcoming the resistance until the Release Button returns to the "Latched" position. The slam latch will come over the front of the tablet. There will also be an audible confirmation as the latch system springs downward.
3. Optional - With the dock in the "Latched" position, turn the lock to the "LOCKED" position (CW).



Insert Bottom First




Rotate Top

"Latched" Position



"Un-Locked" Position



"Locked" Position

## OPERATION - UNDOCKING

1. Turn the lock to the "UNLOCKED" position (CCW).
2. With your hand on the top of the tablet, push up on the blue Release Button until the computer is free to move forward. While the dock is "Un-Latched", pull the top of the tablet forward until it clears the dock. This can be done right or left handed.
3. Remove the computer by pulling it away from the dock.



# Regulatory Certification Information

Regulatory Model #: 7160-1275

GJ Model #'s & Description:

7160-1275-20(-P)(-E) Cradle-Panasonic FZ-T1 Tablet- W/Lock  
7160-1275-10(-P)(-E) Cradle-Panasonic FZ-T1 Tablet

Certifications:

- EN 55032:2012/AC: 2013
- FCC 47 CFR Part 15B Class B
- EN 50581:2012 ROHS2 Directive 2011/65/EU
- EN62368-1:2014+A11:2017
- IEC 62368-1:2014
- UL 62368-1:2014
- CAN/CSA C22.2 No. 62368-1:2014
- UN ECE R10: 2014 Add. 9, Revision 5

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions. (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Gamber-Johnson LLC, 3001 Borham Ave.,  
Stevens Point, WI, 54481, USA, 715-344-3482