

QUICK GUIDE

2-IN-1 KEYBOARD, TAB ACTIVE PRO4/5



A. FEATURES

1. Top Latch Ridge
2. Cover
3. Hinge
4. Pogo Pins
5. Plastic Keys
6. Touchpad
7. Mouse Buttons
8. Built-in Kickstand
9. USB-C Power Port
10. USB 2.0 Input Port
11. Part Number Label



B. IMPORTANT INFORMATION

- Compatible with the Samsung Tab Active Pro4/5 only
- Temperature Range:
 - Operating -20°C to 50°C
 - Storage -40°C to 85°C
- FCC, CE, RoHS, REACH, C-Tick compliant
- This product is NOT designed to be vehicle mounted.
- Connect power cable to USB-C Power Port (Feature 9)
- Connect a flash drive or other digital data device to the USB 2.0 port on the side of the keyboard (Feature 10)
- Reference the Part Number Label for product information regarding any service needs (Feature 11)

C. HOW TO DOCK & UNDOCK THE TABLET

Lift the Cover.



Insert Tablet into tray with Pogo Pins.



Snap Top Latch Ridge over top of Tablet.



On both sides, push up on Top Latch Ridge & pull forward on back corner of Tablet.



Thank you for choosing Gamber-Johnson for your keyboard needs. To learn more visit gamberjohnson.com and search part number 7160-1994.

QUICK GUIDE

2-IN-1 KEYBOARD, TAB ACTIVE PRO4/5



C.a. HOW TO DOCK

Lift the Cover.



Insert Tablet into tray with Pogo Pins.



Snap Top Latch Ridge over top of Tablet.



C.b. UNDOCKING THE TABLET

On both sides, push up on Top Latch Ridge & pull forward on back corner of Tablet.



Thank you for choosing Gamber-Johnson for your keyboard needs. To learn more visit gamberjohnson.com and search part number 7160-1994.