



INSTALLATION INSTRUCTIONS

Product**7110-1391****DELL LAPTOP RETROFIT POCKET KIT****Revision**

Rev. A

Form

INST-1085

Printing Spec: PS-001

This instruction sheet is for attaching the Gamber Johnson retrofit pockets onto the Dell Latitude 5430 Rugged and Dell Latitude 7330 Rugged Extreme laptops. The retrofit pocket kit will allow both Dell Latitude computers to fit in all Rev Gamber Johnson Dell Laptop Docking Stations.

**Product Mounting Disclaimer**

Gamber-Johnson is not liable under any theory of contract or tort law for any loss, damage, personal injury, special, incidental or consequential damages for personal injury or other damage of any nature arising directly or indirectly as a result of the improper installation or use of its products in vehicle or any other application. In order to safely install and use Gamber-Johnson products full consideration of vehicle occupants, vehicle systems (i.e., the location of fuel lines, brakes lines, electrical, drive train or other systems), air-bags and other safety equipment is required. Gamber-Johnson specifically disclaims any responsibility for the improper use or installation of its products not consistent with the original vehicle manufactures specifications and recommendations, Gamber-Johnson product instruction sheets, or workmanship standards as endorsed through the Gamber-Johnson Certified Installer Program.

© Copyright 2021 Gamber-Johnson, LLC

If you need assistance or have questions, call Gamber-Johnson at 1-800-456-6868



Dell Retrofit Pocket Instruction Sheet

Required Equipment:
Dell Latitude 5430 or 7330 Laptop
Dell Retrofit Pocket Kit


Kit Includes:

- (1) Right Pocket Extender**
- (1) Left Pocket Extender**
- (2) M3.5 x 12mm Screws**



Installation Procedure

1. Remove both left and right front handle screw.



Left Handle Screw

Installation Procedure (Continued)

2. Remove handle and place aside with hardware

Keep original handle screws if pocket extenders will be removed in the future



3. Place both left and right pocket extender onto the front of the laptop.

- Pocket extenders are labeled R and L



- Align rear tab on pocket extenders with front pockets on the laptop



Installation Procedure (Continued)

4. Re-attach front handle using supplied screws, sandwiching the pocket extenders between the handle and front of laptop.
 - Do not over-tighten screws - recommended torque = 8in/lbs



5. Perform a fit-check to ensure the Laptop docks in and releases properly.

